

SM2 Series SE Smart Camera User Manual

V2.5.4. 2025

Preface

Purpose

This Manual is a basic description of SM2 series Smart Cameras, which mainly includes the product description, quick installation guide and Simple introduction of SDK(SM-Datum). This manual may be updated due to product upgrades or other reasons. If you need, please contact the sales engineer for the latest version of this manual.

Copyright ©2024

Hangzhou Vision Datum Technology Co., Ltd.

Tel.: +86 571-86888309

Add.:No. 8 Xiyuan 9th Road, West Lake District Hangzhou Zhejiang 310030 China.

All rights reserved. The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and/or service Vision Datum manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Vision Datum.

Disclaimer

The information and specifications described in this manual are subject to change without notice.

Latest Manual Version

For the latest version of this manual, see the Download Center on our web site at: <http://www.visiondatum.com/en/service/005001007.html>

Technical Support

For technical support, e-mail: support@visiondatum.com.

Warranty

To ensure that your warranty remains in force, adhere to the following guidelines:

Do not remove the camera's serial number label

If the label is removed and the serial number can't be read from the camera's registers, the warranty is void.

Do not open the camera housing

Do not open the housing. Touching internal components may damage them.

Prevent ingress or insertion of foreign substances into the camera housing

Prevent liquid, flammable, or metallic substances from entering the camera housing. If operated with any foreign substances inside, the camera may fail or cause a fire.

Avoid electromagnetic fields

Do not operate the camera in the vicinity of strong electromagnetic fields. Avoid electrostatic charging.

Clean with care

Avoid cleaning the sensor if possible.

Handle this camera with care

Do not abuse the camera. Avoid striking, shaking, etc. The camera could be damaged by improper handling.

Read the manual

Read the manual carefully before using the camera.

CHAPTER 1

PRODUCT DESCRIPTION

Product Introduction

With built-in positioning and measurement algorithms, the SM2 series vision sensor can detect an object's existence, count patterns, spots, etc. It can be monitored and operated via the SM-Datum client. It can output results via RS-232 and Ethernet, and cooperate with other processes via IO. The vision sensor supports multiple result output methods and customized result text output. It is easy to use and widely used in industrial fields.

LEO series industrial cameras compatible with GigE、10GigE、USB3.0、Cameralink and CoaXPress data bus standards, support GenICam、USB3 Vision® and GigE Vision®, Smoothly connect with third-party software, like HALCON and Vision Pro, not need for secondary development. LEO series cameras with excellent cost performance and very suitable for various inspections measurement and high-speed imaging applications. This series cameras won customers high praise because its outstanding performance in cellphone and tablet PC screen inspection, LED automatic packaging, defect inspection, and electronic components manufacturing, wafer positioning and other applications.

With this variety of sensors and interfaces, combined with the extensive features offered, LEO series cameras are fit for a wide range of vision applications.

Product Features

- Adopts Built-in hardware platform for high-speed image processing
- Built-in high-precision positioning, measurement, calibration, logic, defect detection, OCR and code reading algorithms
- Output results via RS-232 and Ethernet, and cooperate with other processes via I/O
- Optional multi-color light source、Optional multi-focal length lens, multi-focal length lens optional
- Support Serial, TCP, UDP, FTP, Modbus and other communication modes

* The camera functions may differ by camera models, please refer to actual functions

Status LED Description

| Status LED | Description |
|---------------|---|
| PWR Indicator | It is a power indicator. The indicator is red during the device's power on process. After the device is powered on, the indicator is green. |
| LNK Indicator | It is a network status indicator. The indicator is flashing green when the network transmission is normal. Otherwise, it is unlit. |
| STS Indicator | It is a status indicator. The indicator is green when the device operate normally. When errors occur during the device starts or operates, it is red. |

Mechanical Dimensions

The dimensions is in millimeters:

The cameras are interfaced to an external circuitry via 17-pin connectors located on the housing and contain power, I/O, Ethernet, and serial signals. The interface is threaded. Tightening the interface during use can reduce the loosening of the interface caused by on-site vibration. There are three indicators on the side of the device that show the device status. There are M2/M3 screw holes on the side and bottom of the device for fixing the device.

Camera Housing and Base Mounting Hole Size(mm):




Fig. 1-1: 46 × 57.6 × 25 mm Mechanical Dimensions (in mm) of the Smart Cameras with M12-Monut housing (The installation uses M3 screws).




Fig. 1-2: 46 × 38 × 25 mm Mechanical Dimensions (in mm) of the Smart Cameras with M10-Monut housing (The installation uses M2 screws).

CHAPTER 2

POWER AND I/O INTERFACE DEFINITION

I/O Connection Definition and Assignments

Different models of smart camera power supply and I/O interface correspond to different pin signal definitions.




Table 2-1:
Numbering and assignments for 17-pin Power, I/O and serial ports

■ Equipment shown in Fig. 1-1

| Color | Pin | Signal | Signal Source | Designation | Cable | |
|--------|-------|-----------|---------------|--|--------------------------|----------------|
| Red | 1 | POWER_IN | - | Direct current power supply positive | 8-pin terminal | |
| Brown | 2 | OUT_COM | - | Output signal ground | 8-pin terminal | |
| Purple | White | 3 | - | - | Do not use it for wiring | |
| Green | 4 | RS-232 TX | - | RS-232 serial port output | DB9 female serial port | |
| Green | White | 5 | RS-232 RX | RS-232 serial port input | DB9 female serial port | |
| Yellow | 6 | MDI0+ | - | Fast Ethernet signal MDI0+ | RJ45 Ethernet connector | |
| Orange | White | 7 | MDI1- | Fast Ethernet signal MDI1- | RJ45 Ethernet connector | |
| Blue | White | 8 | GPIO2 | Line 2+ | Non-isolated input | 8-pin terminal |
| Blue | 9 | IN_COM | - | Input signal ground | 8-pin terminal | |
| Brown | White | 10 | GPIO3 | Line 3+ | Non-isolated output | 8-pin terminal |
| Black | 11 | GND | - | Direct current power supply negative | 8-pin terminal | |
| Pink | 12 | - | - | - | Do not use it for wiring | |
| Purple | 13 | - | - | - | Do not use it for wiring | |
| Yellow | White | 14 | MDI0- | Fast Ethernet signal MDI0- | RJ45 Ethernet connector | |
| Orange | 15 | MDI1+ | - | Fast Ethernet signal MDI1+ | RJ45 Ethernet connector | |
| Gray | 16 | GPIO0 | Line 0+ | Bi-directional non-isolated I/O, and it is the trigger by default. | 8-pin terminal | |
| White | 17 | GPIO1 | Line 1+ | Bi-directional non-isolated I/O, and it is used to switch projects by default. | 8-pin terminal | |

The I/O definitions in this manual apply only to Vision Datum standard cables for Smart cameras. Connect according to the I/O types and pinout. Using cables with different color codes from other manufacturers may cause incorrect connections and damage the camera. Always use Vision Datum standard cables.


I/O Connection Definition and Assignments

■ Equipment shown in Fig. 1-2

| Color | Pin | Signal | Signal Source | Designation | Cable |
|--------|-------|-----------|---------------|--|--------------------------|
| Red | 1 | POWER_IN | - | Direct current power supply positive | 8-pin terminal |
| Brown | 2 | GND | Line 0/1/2/3- | Direct current power supply negative | 8-pin terminal |
| Purple | White | - | - | - | Do not use it for wiring |
| Green | 4 | RS-232 TX | - | RS-232 serial port output | DB9 female serial port |
| Green | White | RS-232 RX | - | RS-232 serial port input | DB9 female serial port |
| Yellow | 6 | MDIO+ | - | Fast Ethernet signal MDIO+ | RJ45 Ethernet connector |
| Orange | White | MDI1- | - | Fast Ethernet signal MDI1- | RJ45 Ethernet connector |
| Blue | White | GPIO2 | Line 2+ | Non-isolated Input | 8-pin terminal |
| Blue | 9 | GND | Line 0/1/2/3- | Direct current power supply negative | 8-pin terminal |
| Brown | White | GPIO3 | Line 3+ | Non-isolated output | 8-pin terminal |
| Black | 11 | GND | - | Direct current power supply negative | 8-pin terminal |
| Pink | 12 | - | - | - | Do not use it for wiring |
| Purple | 13 | - | - | - | Do not use it for wiring |
| Yellow | White | MDIO- | - | Fast Ethernet signal MDIO- | RJ45 Ethernet connector |
| Orange | 15 | MDI1+ | - | Fast Ethernet signal MDI1+ | RJ45 Ethernet connector |
| Gray | 16 | GPIO0 | Line 0+ | Bi-directional non-isolated I/O, and it is the trigger by default. | 8-pin terminal |
| White | 17 | GPIO1 | Line 1+ | Bi-directional non-isolated I/O, and it is used to switch projects by default. | 8-pin terminal |

17-pin M12 Cable with Fast Ethernet Interface

Order Model: VT-M1217P2RJ45-3M(SM2)



* The network transmission part of the 17-pin cable corresponding to 6th, 7th, 14th, and 15th pins has been made into an RJ45 interface, and there is no need to wire it yourself.

* The DB9 serial port connector corresponds to 4th and 5th pins of the device's 17-pin interface.


You cannot use the 12V power plug open line and DB9 female serial port connector at the same time. Otherwise, damaging to power supply may occur.

* The 8-pin connector corresponds to other pins of the device's 17-pin interface. You can wire according to the actual demands.

* The open line corresponds to 3rd, 12th, and 13th pins of the device's 17-pin interface.



The open lines of the supplied 17-pin cable cannot be wired with the Fig.1-1 device.



| Color | Pin | Signal | Description |
|-------|-------|----------|---|
| Brown | 1 | DO_5 | - |
| Blue | 2 | DO_4 | - |
| Brown | White | DO_3 | Non-isolated Output |
| Blue | White | DI_2 | Non-isolated Input |
| White | 5 | DI_1 | It can be configured as input or output, and is input by default. |
| Gray | 6 | DI_0 | It can be configured as input or output, and is input by default. |
| Black | 7 | GND | DC Power Supply Negative |
| Red | 8 | POWER_IN | DC Power Supply Positive |

You cannot use DB9 female serial port and VCC to power the device at the same time. Otherwise, damaging to power supply may occur.

The I/O definitions in this manual apply only to Vision Datum standard cables for Smart cameras. Connect according to the I/O types and pinout. Using cables with different color codes from other manufacturers may cause incorrect connections and damage the camera. Always use Vision Datum standard cables.


IO Box

i Appearance here is for reference only. Please refer to the actual one.

| Type | Usage |
|------|---|
| V1.0 | The IO box can be used for switching pull-up and pull-down resistors for each IO channel. |
| V2.0 | The IO box can be used for upgrading the non opto-isolated IO to opto-isolated IO. |


i If the field space is limited and the device IO is not available via the IO box, please purchase the resistor separately and refer to the user manual of the respective device for the IO wiring.

The IO box is used to connect the power supply and I/O interfaces of the device. When wiring the four I/O interfaces of the device on your own, you need to connect pull-up or pull-down resistors to ensure the device operates properly. At this time, resistors need to be prepared and wired by yourself, which is quite troublesome. However, the 8-pin I/O box V1.0 has built-in pull-up or pull-down resistors on each I/O channel, allowing for quick I/O wiring.



- Left-side interfaces: 8-pin terminal for connection of device with a supplied cable.
- Right-side interfaces: VCC and GND are used to connect to switch power supplies or power adapters to power the devices equipped with the IO box.
 - V1.0: Out of the rest six pins, four are used to connect to external NPN or PNP devices for receiving external trigger signals or sending signals to external devices. Among the six pins, two are set aside.
 - V2.0: The rest are I/O signal lines or signal grounds to connect external NPN or PNP devices for receiving external trigger signals or sending signals to external devices.

V1.0 Internal Circuit



- You can use IO box to connect NPN/PNP devices to access to pull-up and pull-down resistors.
- Industrial code reader: You should use the Vision Datum cable to connect the code reader to the top terminal of the IO box.
 - External devices: You should connect external devices to the bottom terminal of the IO box.
 - Pull-up and pull-down resistors: if the DIP switch is switched to DOWN, pull-down resistor is connected. If the DIP switch is switched to UP, pull-up resistor is connected.

i

- The current IO box has the default pull-up shorted to the device power supply VCC. When powered on, the output level is equal to the device VCC. Please pay attention to voltage matching during the connection with the device.
- The default pull-up resistor of the IO box is 10 KΩ, and the default pull-down resistor is 1.1 KΩ. In actual use, please note the driving capability of the pull-up/down and the voltage division issue.


IO Box

V1.0 I/O Wiring

When connecting an external device to trigger input/output via an IO box, there are several wiring methods for different scenarios, as shown in the table below. You can select an appropriate wiring method according to your actual needs.


| Applicable I/O | Applicable Scenarios |
|----------------|---|
| Input Only | Connect to an external PNP device via the pull-down resistor within the IO box. |

Connecting to PNP Device



| Applicable I/O | Applicable Scenarios |
|------------------|---|
| Input and Output | Connect to an external NPN device via the pull-up resistor within the IO box. |


Connecting to NPN Device



- The left side of the wiring diagram is a silkscreen information on the IO box. The order of the information may differ from the actual IO box. Please refer to the wiring diagram and silkscreen information on the actual IO box to wire the device.
- When the input interface connects to external switch signals and the output interface connects to external PNP devices, it is not necessary to use the IO box as an intermediary. You can directly use the cables supplied with the device for wiring. For detailed wiring instructions, please refer to the user manual of the corresponding device.

IO Box


V2.0 Internal Circuit



The color corresponds to the color of the cable at the 8-pin terminal.

V2.0 Opto-Isolated Input

A diagram of the opto-isolated input circuit in the IO box is shown in the following figure.



The voltage of the opto-isolated input is from 5 VDC to 24 VDC, and breakdown voltage is 30 V. Please keep the voltage stable.


The electrical feature of the opto-isolated input signal is shown in the table below.

| Parameter Name | Value |
|-------------------------------|--------------|
| Opto-Isolated Turn-On Voltage | 2 V |
| Input Falling Delay | 81.6 μ s |
| Input Rising Delay | 7 μ s |

IO Box

V2.0 Opto-Isolated Output

A diagram of the opto-isolated output circuit in the IO box is shown in the following figure.



- i** ● The voltage of the opto-isolated output is from 5 VDC to 24 VDC, and the max. output current is 100 mA.
- I/O outputs cannot be used directly with inductive loads, such as DC motor.


The electrical feature of the opto-isolated output signal is shown in the table below.

| Parameter Name | Value |
|-------------------------|---|
| Output Falling Delay | 6.3 μ s |
| Output Rising Delay | 68 μ s |
| Output Residual Voltage | <ul style="list-style-type: none"> ● Output residual voltage is proportional to drive current. ● The residual voltage is 2.5 V when the drive current is 25 mA. |

- i** The current and output logic level low of the output signal may vary slightly when the external voltage and resistance are different.

V2.0 DIP Switch

The bi-directional I/O (GPIO0/1) has opto-isolated input and output circuits that can be switched via a DIP switch. The DIP switch and operation method are shown in the following figure.



- i** When using bi-directional I/O, please ensure that the I/O mode on the client software is consistent with the settings on the DIP switch. Both are set to input or both to output. Otherwise, it will not work.

IO Box

V2.0 I/O Wiring

When connecting an external device to trigger input/output via an IO box, there are several wiring methods for different scenarios. You can select an appropriate wiring method according to the actual needs.




For the following wiring diagrams, please note the following information.

- The left side of the wiring diagram is a silkscreen information on the IO box. The order of the information may differ from the actual IO box. Please refer to the wiring diagram and silkscreen information on the actual IO box to wire the device.
- For the the input/output properties of the signal line and the signal ground should be matched. If IN2 or GPIO0/1 is used in the signal line, and GPIO0/1 is set to IN0/1, the device power ground should be connected to IN-COM. If OUT3 or GPIO0/1 is used in the signal line, and GPIO0/1 is set to OUT0/1, the device power ground should be connected to OUT-COM.
- When connecting to the external device via IN2 or GPIO0/1 (GPIO0/1 is set to IN0/1) of the IO box, you need to set different trigger-related parameters based on the implementation principle of internal opto-isolated input.

Wiring Diagram 1: When the IO box is connected to external PNP devices for input or output



When wiring, the trigger parameters need to be set in reverse. That is, if an external device is required to send a low-level signal to the IO box for triggering the device, the parameter Trigger Type should be set to Level High.




Wiring Diagram 2: When the IO box is connected to external NPN devices for input or output, no external pull-up resistors are required at this time.



When wiring, you do not need to reverse the trigger-related parameters. You can directly set the parameters according to the actual signal level. Specifically, if an external device is required to send a low-level signal to the IO box for triggering the device, you can select the Level Low.

- When IO box input connecting to external NPN device, you can refer to the following wiring method in most cases. However, in some cases, you should refer to Wiring Diagram 3 for wiring.
- When IO box output connecting to external NPN device, you can refer to the following wiring method in all cases.



INSTALLATION AND SETUP

You should perform the software installation procedure first and the hardware installation procedure second.

Software Installation

■ SM-Datum Installation

If you use a firewall on your computer, disable the firewall for the network adapter to which your camera is connected.

Close the Firewall

In order to ensure the camera software keep running and image transmission stability, please close the firewall before using the software.

System Requirements

LEO Camera Software Suite for Windows requirements that one of the following operating systems is installed on your computer:

- Windows 7 (32 bit or 64 bit)
- Windows 10 (32 bit or 64 bit)

Installation Steps

- 1.You can download the SM-Datum software (Smart Cameras SDK For Windows) from:
<http://www.visiondatum.com/service/005001008.html>
- 2.Double click SM-Datum installation package to install the client.
- 3.Follow the instructions on the screen. The installer will guide you through the installation process.

Hardware Installation

■ Camera Installation

The installation procedures assume that you will be making a peer-to-peer connection between your camera and a computer.

Make sure that the following items are available before starting the installation:

- SM2 Series Smart camera
- Applicable switch or network card
- The computer with a GigE network adapter installed
- The computer must be equipped with appropriate operating system
- Standard Ethernet cable (CA5 or above).

Steps:

- Use M2/M3 screws to fix the device to the installation position.
- Use the supplied 17-pin cable to wire the device to a suitable power adapter or switch power supply.
- Use the network cable to connect the device via the 17-pin cable's RJ45 connector to a switch or a network interface card.

Network Settings

Before using the camera, you need to configure IP is in the same network segment with the computer. You can modify it in "Local Connection" to ensure network communication is normal.

Local Network Configuration :



- Click "Control Panel"> "Network and Internet"> "Network and Sharing Center"> "Change Adapter Configuration. "Then select corresponding network card to configure it automatically obtain IP address or manually assign it as same network segment address with the camera. Shown as below:

- Select NIC and set the IP obtainment mode.

- 1) Select Obtain an IP address automatically to get an IP address of the PC automatically.
- 2) Or select Use the following IP address to set an IP address for the PC manually.

- Set NIC property.

- 1) Go to NIC settings page: Control Panel → Hardware and Sound → Device Manager → Network Adapter.
- 2) Select corresponding network interface card, and click Link Speed.
- 3) Set Speed and Duplex as Auto-Negotiation or 100 Mbps.



Software Operation

■ SM-Datum Operation

1. Double-click the SM-Datum shortcut on the desktop to open up the client software.
2. The Software refreshes the camera list automatically. To add a remote camera, click  type in the IP address.



Make sure the connection between the remote camera and the PC is established when adding remote cameras.

3. Make sure that the device to be connected is available  and selected.



You cannot log in if the device is occupied or unreachable. It must be restored to the available state before logging in.

- The camera is occupied by another process . Log out the camera from the current process before you can log into the camera via the Software.
- The camera's IP address is not reachable on the LAN . Click Edit IP Address or click  before you can log into the camera.


4. Enter the device password on the right and click  to log in.



- The camera password will be restored to Abc1234. We highly recommend you change the password after login to ensure the security of your device.
- If you forgot the password of a camera, you can click Forgot password to show the password reset window. Contact our technical support to get the password reset file. If you choose to send an email, please include the serial number of the camera in the content. After getting the password reset file, click Import Resetting File. Click Open to load the key file and reset the password.

Device Operation


After login, the software main interface as below.



See the description of each area in the table below.

| No. | Name | Description |
|-----|-----------------------|---|
| ① | Menu Bar | Related settings can be made for program management, I/O settings, communication settings, camera settings, operation management and camera monitoring. |
| ② | Project Control Panel | View project running status in real time, reset project statistics, run/stop project, and edit project. |
| ③ | Tool List | View the real-time status of each tool in the project and edit tools. |
| ④ | Live View Panel | View the image of the camera in Camera Mode or imported image in Image Mode. |
| ⑤ | More | Check user manual, and check software version. Minimize, maximize, and exit the Software. |

The device needs to perform related operations through the client. The overall operation process is shown in the following figure.



For details, please refer to the client user manual. Click "More" in the upper right corner of the client and select "User Manual" to open the client user manual.

CHAPTER 4

I/O ELECTRICAL FEATURE
AND WIRING

I/O Electrical Feature


The device has four I/O interfaces and one RS-232 serial port. The four I/O interfaces include one input signal (Line 2), one output signal (Line 3), and two bi-directional I/Os (Line 0/1) that can be configured as input or output.




By default, the I/O type of Line 0 is trigger, and the I/O type of Line 1/2 is used to switch project.

■ Input Signal

The device has one input signal (Line 2) and two configurable bi-directional I/Os (Line 0/1) that can be configured to input signal, and their internal circuit is shown below.



The maximum input current for the input signal is 1 mA.



Input Electrical Feature:

| Parameter Name | Parameter Symbol | Value |
|------------------------|------------------|-----------|
| Input Logic Level Low | VL | 1 V |
| Input Logic Level High | VH | 2 V |
| Input Rising Delay | TDR | 1 μ s |
| Input Falling Delay | TDF | 200 ns |


I/O Electrical Feature

Output Signal

The device has one output signal (Line 3) and two configurable bi-directional I/Os (Line 0/1) that can be configured to output signal, and their internal circuit is shown below.



The max. output current is 25 mA.



When the external voltage is 12 VDC and pull-up resistor is 1 K Ω , output electric feature is shown below.

| Parameter Name | Parameter Symbol | Value |
|-------------------------|------------------|------------------------------------|
| Output Logic Level Low | VL | 500 mV |
| Output Logic Level High | VH | 12 VDC (external pull-up resistor) |
| Output Falling Delay | TDF | 330 ns |
| Output Rising Delay | TDR | 4.4 μ s |
| Output Falling Time | TF | 116 ns |
| Output Rising Time | TR | 3.8 μ s |

Relation between different external voltages and output logic level low is shown below.

| External Voltage | VL |
|------------------|--------|
| 3.3 V | 180 mV |
| 5 V | 260 mV |
| 12 V | 500 mV |
| 24 V | 900 mV |

I/O Wiring

The device can receive input signals from external devices and output signals to external devices. This section only introduces how to wire the device to other external device. If you use the IO box, please check the wiring diagram instructions of the IO box according to the IO box in your hand.




- The input and output signals mentioned in this section are the bi-directional I/O signal whose I/O type is configured as trigger and output correspondingly.
- The voltage of VCC should be equal to or less than that of PWR. Otherwise, the device's output signal may have exception.


■ Bi-directional I/O Wiring

Input/output signal wiring may differ by the type of the external device.


- When the bi-directional I/O is set as the non-isolated input signal for connecting to the PNP device, you should use a 1 K Ω pull-down resistor.



- When the bi-directional I/O is set as the non-isolated output signal for connecting to the PNP device




- When the bi-directional I/O is set as the non-isolated input/output signal for connecting to the NPN device, you should use a 1 K Ω pull-down resistor.



I/O Wiring

- When the bi-directional I/O is set as the non-isolated input signal for connecting to the switch.




RS-232 Serial Port

The device supports outputting data via RS-232 serial port, and you can set serial port communication via the client software. Refer to the user manual of the SM-Datum client software for details. The 17-pin cable has open lines of RS-232 serial port, which are 4th and 5th pin of the 17-pin interface.

■ RS-232 Serial Port Introduction

The supplied 17-pin cable has a RS-232 serial port. Refer to the figure and table below for pin definitions.


- The definition of the 9-pin male 232 serial port connector is as follows.



| Pin | Symbol | Description |
|-----|--------|---------------|
| 2 | RX | Receive Data |
| 3 | TX | Send Data |
| 5 | GND | Signal Ground |

■ RS-232 Serial Wiring

The wiring of the unit's RS-232 interface to other external devices with RS-232 serial ports is shown below.



Trouble Shooting

Trouble:

■ No device found when running the client

Possible Reason1: The device is not powered on

Solution1: Check whether the power connection of the device is normal (observe whether the top PWR light is solid green), and ensure that the device is powered on normally.

Possible Reason2: The network connection is abnormal

Solution2: Check whether the network connection is normal (Observe whether the top LNK light is flashing green, and the ACT light is solid yellow), make sure that the network cable of the device is connected normally, and the PC network port and the device are in the same network segment.

■ Live view is black/dark

Possible Reason1: The brightness of the light source is not enough

Solution1: Appropriately increase the brightness of the light source or replace it with a brighter light source.

Possible Reason2: The exposure and gain are adjusted too low

Solution2: Appropriately increase exposure and gain.

■ Image freezes / low frame rate / tearing during preview

Possible Reason: The network line speed is not 1000Mbps

Solution: Check if the network transmission speed is 1000Mbps and above.

■ No image when previewing

Possible Reason: Enable trigger mode, but no trigger signal

Solution: Trigger the device or turn off the trigger mode.

CHAPTER 6 TECHNICAL SUPPORT

Technical Support

If you need advice about your camera or if you need assistance troubleshooting a problem with your camera, it's highly recommended to describe your issue in details and contact us via E-mail at support@visiondatum.com

It would be helpful if you can fill-in the following table and send to us before you contact our technical support team.

| | | | |
|---|--|--------------|--|
| Camera Model: | | Camera's SN: | |
| Describe the issue in as much detail as possible: | | | |
| If known, what's the cause of the issue? | | | |
| How often did/does the issue occur? | | | |
| How severe is the issue? | | | |
| Parameter set | Please connect the camera directly to PC and make note of the parameter when the issue occurred. | | |

Hangzhou Vision Datum Technology Co., Ltd

No.8 Xiyuan 9th Road, West Lake District Hangzhou Zhejiang 310030 China
Tel: 86-571-86888309
www.visiondatum.com